## Subject: RailML infrastructure\_V094-17\_2004-02-23 Posted by ron.van.kampen on Fri, 26 Mar 2004 15:53:16 GMT View Forum Message <> Reply to Message

We are developing a conversion program from a data base containg the dutch railway infrastructure to RailML infrastructure\_V094-17\_2004-02-23.

2 questions came up during this development:

- 1) Given 2 parallel tracks with singleCrossOvers. How can one specify the isolator(s) in the singleCrossOver?
- 2) A block has a required attribute called type. Possible block types are: main, auto, LZB. I know dutch railways (NS) do not use LZB, but which one of the remaining two should I use: main or auto? Can someone please explain to me what main and auto block types mean?

Best regards,

-- Ron

Subject: Re: RailML infrastructure\_V094-17\_2004-02-23 Posted by Ulrich Linder on Sun, 28 Mar 2004 23:51:18 GMT View Forum Message <> Reply to Message

Hello,

"Ron van Kampen" <ron.van.kampen@siemens.com> schrieb im Newsbeitrag news:5Dkuzp0EEHA.492@sifa...

- > We are developing a conversion program from a data base containg the dutch
- > railway infrastructure to RailML infrastructure\_V094-17\_2004-02-23.

> 2 questions came up during this development:

> 1) Given 2 parallel tracks with singleCrossOvers.

> How can one specify the isolator(s) in the singleCrossOver? The CrossOver is a short form of two switches. If you want to specify informations about the track between the two switches (i.e. isolators), use two switches and a short track between the switches.

- > 2) A block has a required attribute called type. Possible block types are:
- > main, auto, LZB. I know dutch railways (NS) do not use LZB, but which one
- > of the remaining two should I use: main or auto? Can someone please
- > explain to me what main and auto block types mean?

Auto is an automatic block system, man (not main!) is a manual block.

> Best regards,

> > -- Ron

Today, a new schema recommendation is published (V0.94-18, see below). It will be presented on the next RailML meeting (Friday, 2004-04-02 in Braunschweig). We plan to publish a stable version V1.0 in the next weeks. Please use the Versions below V1.0 only for testing.

With best regards

Ulrich Linder

-----

Dipl.-Ing. Ulrich Linder Linder Rail Consult

D-14169 Berlin

Tel. +49.30.84 72 56 87 Fax. +49.30.84 47 11 56

Email mailto:Ulrich.Linder@linder-rail-consult.de www http://www.Linder-rail-consult.de