
Subject: Re: meaning of 'up' and 'down' in mileageChange.dir and track.mainDir
Posted by [Christian Rahmig](#) on Wed, 03 Oct 2012 08:03:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hello Dirk,

>> In addition to the changes for the element <mileageChange>, it is now
>> possible to define an absolute (mileage) direction at the beginning of a
>> track, too. The type tTrackNode has been extended by the new attribute
>> "absDir" providing the values 'raising' and 'falling'.

>

> At least for 3.0, I would prefer a solution which describes the mileages
> in _one_ structure for easier parsing. (With the above mentioned
> changes, the mileages currently are described in the structures
> <trackBegin>, <trackEnd>, and <mileageChanges>.)

thank you for your good remark. I created a new trac ticket [1] in order
not to forget about this aspect as well as the absDir attribute in
railML 3.0.

[1] <https://trac.assembla.com/railML/ticket/166>

Regards

--

Christian Rahmig
railML.infrastructure coordinator
