## Subject: valueTableType

Posted by Martin Jacob on Thu, 30 Jun 2005 15:29:43 GMT

View Forum Message <> Reply to Message

Hello,

I would like to ask how to use the valueTableType with more than one row. As I understand the element valueLine should

can occure at least once up to undounded but at the moment it has to occure exactly once.

May we change the occurance of valueLine to 1..\*?

Martin

Subject: Re: valueTableType
Posted by Joerg von Lingen on Tue, 12 Jul 2005 13:01:23 GMT
View Forum Message <> Reply to Message

Martin.

yes, this was clearly a mistake. It will be rectified in the new schema version.

```
<xsd:element name="valueLine" maxOccurs="unbounded">
 <xsd:annotation>
  <xsd:documentation>set of values related to a speed value (one table
line)</xsd:documentation>
  <xsd:documentation>History:
V0.93 added
    V1.01 changed maxOccurs to "unbounded" to allow one line per speed
value</xsd:documentation>
 </xsd:annotation>
 <xsd:complexType>
  <xsd:sequence>
   <xsd:element name="values" maxOccurs="unbounded">
     <xsd:annotation>
       <xsd:documentation>the values related to a speed value
themselves</xsd:documentation>
     </xsd:annotation>
    </xsd:element>
   </xsd:sequence>
  <xsd:attribute name="speedValue" type="xsd:decimal" use="required"/>
 </xsd:complexType>
</xsd:element>
```

Regards, Jörg von Lingen Martin Jacob wrote the following on 30.06.2005 17:29:

> Hello,

>

- > I would like to ask how to use the valueTableType with more than one row. As I understand the element valueLine should
- > can occure at least once up to undounded but at the moment it has to occure exactly once.

>

> May we change the occurance of valueLine to 1..\*?

>

> Martin