
Subject: Crossings

Posted by [claus.messauer](#) on Wed, 31 Mar 2004 07:03:21 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hello,

I have a question concerning crossings. In the infrastructure scheme version 0.93, crossings could be defined with the element junction (enumeration type: simpleSwitch, simpleCrossing, simpleSwitchCrossing, double switchCrossing). Where can I define crossings in the scheme 0.94?

I think there is a little mistake in the technical reference. Possible types of a block are man (in the reference main), auto and LZB.

Best regards
Claus

Subject: Re: Crossings

Posted by [Ulrich Linder](#) on Wed, 31 Mar 2004 13:52:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hello,

"Claus Messauer" <claus.messauer@alcatel.at> schrieb im Newsbeitrag news:trOsA5uFEHA.1168@sifa...

> Hello,

>

> I have a question concerning crossings. In the infrastructure scheme
> version 0.93, crossings could be defined with the element junction
> (enumeration type: simpleSwitch, simpleCrossing, simpleSwitchCrossing,
> double switchCrossing). Where can I define crossings in the scheme 0.94?
Crossings will be defined in the next schema release as a kind of connection.

> I think there is a little mistake in the technical reference. Possible
> types of a block are man (in the reference main), auto and LZB.
I've updated this bug in my internal documents. It will be published within the next schema release.

With best regards

Ulrich Linder

Dipl.-Ing. Ulrich Linder
Linder Rail Consult

D-14169 Berlin

Tel. +49.30.84 72 56 87

Fax. +49.30.84 47 11 56

Email <mailto:Ulrich.Linder@linder-rail-consult.de>

www <http://www.Linder-rail-consult.de>
